PowerLite Home Cinema 705HD

DESCRIPTION	PART NUMBER
Remote Control	1515069
Power Cable (6’ 4”)	2126917
Lamp (V13H010L41)	1519600
Component Video Cable	2118180

Order user replaceable parts from an Epson authorized parts distributor.
http://www.epson.com/cgi-bin/Store/AboutEpsonConnection.jsp
---- or ----
Locate an Epson Authorized Service Center to order user replaceable parts by using the “Help me find…” tool in the right column of the Epson Support home page.
http://www.epson.com/cgi-bin/Store/support/SupportIndex.jsp

Changes and additions shown in BLUE